RESIDENTIAL & COMMERCIAL

INDUSTRIAL & MARINE

ART & CRAFT



Epoxy Coving Fast Cure

Complete Kit

Kit Sizes

20 Linear Meter

Product Description	Size	Code	Quantity
Dry Silica Sand	20Kg	SS	1
Fast Cure Clear Epoxy Resin	1.25Lt	FC	1

40 Linear Meter

Product Description	Size	Code	Quantity
Dry Silica Sand	20Kg	SS	2
Fast Cure Clear Epoxy Resin	2.5Lt	FC	1

80 Linear Meter

Product Description	Size	Code	Quantity
Dry Silica Sand	20Kg	SS	4
Fast Cure Clear Epoxy Resin	5Lt	FC	1

Description

SHIMICOAT Epoxy Coving Fast Cure Kit contains Clear Epoxy Resin (100% Solid) and Silica Sand to make Epoxy Mortar with ideal consistency for coving applications. Ideal Kit for installers and applicators requiring fast, professional and compliance coving, especially for commercial applications. Epoxy Mortar Coving provides a high MPa finish surface stronger than 50 MPa concrete.



Kits Include

Commercial Grade Epoxy Coving Fast Cure contains:

- Order size Silica Sand
- Order size Clear Epoxy Resin 100% Solid

Kit Sizes	Dry Silica Sand 20Kg Bag	Fast Cure Clear Epoxy Resin 100% Solid (Lt)
Small (21.5Kg)	1	1.25Lt
Medium (43Kg)	2	2.5L
Large (86Kg)	4	5L



MATERIALS



CHEMICALS



RESINS



EQUIPMENT



Usage

COVING

- Commercial kitchens
- Food processing plants
- **Amenities**

- Laundries
- Factories and warehouses
- Easy wash and flush floor

Applications

Mix 1.25Lt Clear Epoxy Resin (4A:1B), One liter of Part A (Epoxy Resin) and quarter of a liter of Part B (Curing Agent). Add 20Kg bag of Silica Sand into the resin and mix to achieve uniform epoxy mortar. Use Trowel, Scraper or Spatula to apply over the corner and create coving.

Coverage

Linear Meter Coverage of Epoxy Coving Fast Cure

Kit Sizes	Kit Contains	50mm	100mm
Small (21.25Kg)	One bag of 20Kg Silica Sand and 1.25Lt of Clear Epoxy Resin (100% Solid)	20	15
Medium (42.5Kg)	Two bags of 20Kg Silica Sand and 2.5Lt of Clear Epoxy Resin (100% Solid)	40	30
Large (85Kg)	Four bags of 20Kg Silica Sand and 5Lt of Clear Epoxy Resin (100% Solid)	80	60

Dry Time at 25°C

Pot Life:	15 minutes at 25°C
Tack Free:	1-2 hours
Dry Cured:	2-3 hours
Fully Cured:	7 days – Ultimate Hardness
Coating Over Coving:	Immediate









EQUIPMENT